




Made in Italy

3500 Tourmaline Ionic Hair Dryer

INSTRUCTION MANUAL



SAVE THESE INSTRUCTIONS
OPERATING INSTRUCTIONS & SAFETY GUIDE



SAFETY GUIDE

Important — Please carefully read all instructions before using.

IMPORTANT SAFETY INFORMATION

When using this appliance, especially when children are present, these safety precautions should always be followed:

- **READ ALL INSTRUCTIONS BEFORE USING**
- **ALWAYS KEEP AWAY FROM WATER**

DANGER — Electric parts within this appliance are electrically live even when the switch is off.

To reduce the risk of death by electrical shock:

- Always unplug the appliance immediately after using.
- Do not use appliance while bathing or showering.
- Never place or store appliance where it could fall or be pulled into tub or sink.
- Do not place in or drop into water or any other liquid.
- If for any reason the appliance makes contact with water, unplug the appliance immediately and do not reach into water.



WARNING — To reduce the risk of injury, burns, electrocution and fire:

- Never leave appliance unattended while it is operating or plugged into outlet.
- Close supervision is necessary when this appliance is being used by, on, or near children or individuals with certain disabilities.
- Use this appliance only for its intended use as described in this manual.
- Do not use attachments not recommended by the manufacturer.
- Never operate this appliance if the cord or plug has been damaged, if it is not working properly, if it has made contact with water, if it has been dropped and/or damaged in any way.
- Never block the air openings of appliance or place the appliance on a soft surface; such as a bed or couch, where the air openings may be blocked.
- Always keep the air openings free of lint, hair, and/or any other obstructions.
- Keep the cord away from hot or heated surfaces.
- Never wrap the cord around the appliance.
- Never use the appliance while drowsy or sleeping.
- Never drop or insert any object into any appliance opening.
- Do not use outdoors or operate where aerosol (spray) products are being used.
- Do not operate where oxygen is being administered.
- Never use an extension cord in conjunction with this appliance.
- Do not direct hot air towards eyes or other heat-sensitive areas.
- Attachments will be hot during use; allow them to cool before handling.
- Never place appliance on any surface while it is operating or while switch is turned on.
- While using the appliance, keep your hair out of appliance and away from the air inlets.
- Do not put nozzle directly on hair.

IMPORTANT SAFETY INFORMATION

To avoid circuit overload, do not operate another high wattage appliance on the same circuit.


LINE CORD SAFETY:

- Never pull or tug on the cord and/or the appliance.
- To insert plug, grasp it firmly and guide into outlet.
- To disconnect appliance, grasp plug firmly and remove from outlet.
- Before each use, inspect the cord for any cuts and/or abrasion marks. If any imperfections are found, this indicates that the appliance and/or line cord should be replaced.
- Never wrap the cord around the appliance, as this could result in damage to the cord-appliance connection and could cause the cord to fray and break.
- Do not use appliance with any type of extension cord. Plug directly into the electrical outlet.

DO NOT OPERATE APPLIANCE IF THE LINE CORD SHOWS ANY SIGNS OF DAMAGE, IF APPLIANCE WORKS INTERMITTENTLY, OR IF APPLIANCE STOPS WORKING ENTIRELY.

COMPONENTS

DETAILED APPLIANCE COMPONENTS



1. Airflow Button
2. Temperature Button
3. Cool Shot Button

OPERATING INSTRUCTIONS

This appliance is intended for professional use. Use on alternating current (AC) 60 Hz only. This appliance is designed to operate on 120 volts AC only.

This appliance has a polarized plug (one blade is wider than the other). As a safety feature, this plug will fit into a polarized outlet only one way. If the plug does not fit fully into the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do not attempt to defeat this safety feature.

OPERATING INSTRUCTIONS

HOW TO USE:


1. To turn ON, push Speed/ON/OFF switch downwards once for low speed and twice for high speed setting.
2. Three heat settings are available and can be adjusted by pushing the Heat switch to desired position.
3. For bursts of cold air, press and hold the Cold shot button.
4. To turn OFF, push Speed/ON/OFF switch upwards to "0" position.

HOW TO USE THE ALCI:

The ALCI safety device in this unit is built into the plug. This device will make it inoperable under some abnormal conditions, such as accidental immersion in water. If the appliance is immersed in water, do not attempt to reset the ALCI safety device. The ALCI safety device is equipped with a test button so that its operation can be checked.

1. Press the RESET button on the ALCI safety device.
2. Plug your ALCI into an AC outlet, and then press the TEST button.
3. The RESET button will pop out. This verifies the safety device is operating properly. If the RESET button does not pop out, do not use the unit.
4. Press the RESET button to reactivate the ALCI safety device and the appliance is now ready to use.

Repeat this procedure every time you use this appliance to confirm that the safety device is ready and operational.



STYLING

BODY & VOLUME

For extra volume, follow these tips.

1. Bend head upside down while drying.
2. Position the airflow toward the roots for maximum lift.
3. When hair is dry, toss head back and brush hair into place for styling.

STRAIGHTENING

For a sleek straight look, follow these tips.

1. Divide hair into small sections.
2. Using a large 2" diameter brush, hold hair taut, moving the dryer from roots to ends.
3. Bend the ends of hair slightly under as you dry.

MAKING WAVES

For natural-looking waves, follow this tip.

1. Grasp hair at the roots and scrunch hair between fingertips while drying or while using the collapsible diffuser.

COLD SHOT BUTTON

To set your style, press and hold the cold shot button for about 15 seconds after drying. You may have to wait a few seconds after pressing the button for the hair dryer to cool.

SPECIALIZED ATTACHMENTS

For concentrated airflow, use the concentrator nozzle.

It is ideal for blow drying with comb or styling brush.


For softened airflow, use a diffuser.

For volume and lift, use a hair pik.

CARE AND CLEANING

This appliance requires little maintenance and contains no user serviceable parts.

No lubrication is needed. Keep all vents and openings clear of dirt and dust. Do not try to repair the appliance yourself. If any malfunction occurs, unplug the appliance, allow it to cool and return the appliance to the place of purchase.



TO CLEAN: Unplug the appliance before cleaning. This appliance is designed with a removable lint filter. It is absolutely necessary to remove the lint filter and clean out lint and debris on a weekly basis to prolong the life of this appliance and prevent overheating while in use. If cleaning becomes necessary, disconnect the appliance from the power source and wipe the exterior with a damp cloth.

TO STORE: When not in use, unplug the appliance and let it cool. Store the appliance out of reach of children in its box or in a safe, dry location. Never wrap the cord around appliance; this could cause the cord to wear prematurely and break. Do not put any stress on cord where it enters the handle, as it could cause cord to fray and break. Allow the cord to hang or lie loose and straight at the point of entry into the appliance.

SPECIAL ATTENTION

- If the dryer detects an electrical shock hazard, it will immediately shut off. To restore power, press the RESET button on the ALCI safety device to reactivate the circuit.
- This appliance is designed with a protective coating around the heating coils. When operating the first few times, you may notice momentary smoking when turning unit off. This represents no danger to the user and does not indicate a defect in the unit. The smoke should dissipate within a short time.
- Never block the air intake grill, as this will cause the unit to overheat. Turn the unit OFF and clear any obstruction from the air intake grill. Wait 10 minutes before operating the appliance. If the appliance has sustained damage, do not try to repair it. See warranty for further instructions.
- Never touch heating section as it may be hot and can burn you.
- To avoid possible scalp and/or hair burns, use HIGH setting only when hair is wet. Reduce to LOW heat setting as the hair dries.

- To extend the life of this appliance, it is recommended to switch it to the LOW setting for a few seconds before shutting the appliance off.
- Untwist the cord from time to time to avoid tangling and/or damage to cord.



Class II double insulated. This product must not be connected to ground.

WARRANTY INFORMATION

TWO (2) YEAR LIMITED WARRANTY: USA AND CANADA

GammaPiu N.A. (Gamma+) ("we", "us", or "our") warrants product against defects in materials and workmanship for two (2) years from original purchase date ("Warranty Period"). If you cannot prove original purchase date, Warranty Period runs two (2) year from date of product manufacture. If we receive a valid claim, we will repair or replace with product of equal or greater value at our option.

This Warranty does not cover normal wear and tear such as shorts in the power supply cord or plug, or excessive product build-up or damage due to accident, misuse or abuse such as: dropping (broken housing, broken hinges, rattling noise, vibration, etc.), wrong voltage supply, or neglect in safety precautions; or tampering such as repair or attempted repair by unauthorized person, or use of unauthorized attachments.

What to do if you have a claim: If the product fails to operate properly under normal use because of a covered defect; (1) within 90 days from purchase, simply return to place of purchase with valid, dated receipt for a no charge replacement, or (2) after 90 days and within the Warranty Period, please call (888) 864-6409 for further directions on how to send back to us for repair or replacement (postage and handling charges of \$24.95 will apply). Please properly package product against possible damage. We are not responsible for products lost or damaged in transit.

IMPORTANT: Do not send cash. Be sure to enclose a note describing the problem and proof of original purchase date. Further instructions and return address will be provided for the claim process when you call our service center at (888) 864-6409.

TO THE MAXIMUM EXTENT PERMITTED BY LAW, THIS WARRANTY AND THE REMEDIES AND CONDITIONS SET FORTH ARE EXCLUSIVE AND IN LIEU OF ALL OTHER WARRANTIES, REMEDIES AND CONDITIONS, WHETHER ORAL OR WRITTEN, EXPRESS OR IMPLIED. WE SPECIFICALLY DISCLAIM ANY AND ALL IMPLIED WARRANTIES, INCLUDING, WITHOUT LIMITATION, WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. IF WE CANNOT LAWFULLY DISCLAIM OR EXCLUDE IMPLIED WARRANTIES UNDER APPLICABLE LAW, THEN TO THE EXTENT WE CANNOT DISCLAIM WARRANTIES, ALL SUCH WARRANTIES, INCLUDING WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE SHALL EXPIRE ON EXPIRATION OF THE WARRANTY PERIOD. WE EXPRESSLY EXCLUDE, AND WE WILL NOT PAY, CONSEQUENTIAL OR INCIDENTAL DAMAGES FOR THE BREACH OF ANY WARRANTY, AND WE ASSUME NO RESPONSIBILITIES FOR YOUR LOSS OF USE OF THE PRODUCT, OR FOR ANY OTHER INCONVENIENCE OR CONSEQUENTIAL EXPENSE.

YOUR LEGAL RIGHTS: Some countries, states, provinces and/or jurisdictions do not allow limitations on implied warranties and/or do not allow the exclusion of incidental or consequential damages, so the above limitations and exclusions may not apply to you.

If you have questions regarding warranty, you may reach the service center at (888) 864-6409. GammaPiu N.A., 935F NW 31st Avenue, Pompano Beach, FL 33069

GFCI INFORMATION

**IMPORTANT
MESSAGE
TO
CONSUMERS**



**THIS MESSAGE ABOUT
GROUND FAULT CIRCUIT INTERRUPTERS
CAN SAVE A LIFE**

**IF YOU MUST USE YOUR HAIR DRYER IN THE
BATHROOM, INSTALL A GFCI NOW!**

Your local electrician can help you decide which type is best for you – A portable unit that plugs into the electrical outlet or a permanent unit installed by your electrician. The National Electrical Code now requires GFCI's in the bathroom, garages, and outdoor outlets of all new homes.



WHY DO YOU NEED A GFCI?

Electricity and water don't mix if your hair dryer falls in water while it's plugged in, the electric shock can kill you ... **even if the switch is "off."**

A regular fuse or circuit breaker won't protect you under these circumstances. A GFCI offers you far greater protection.

**A GFCI CAN SAVE YOUR LIFE!
COMPARED TO THAT, THE PRICE IS SMALL!
DON'T WAIT... INSTALL ONE NOW!**